

Adhesives

Product	Apply with	Lay Method	Work Time	Cure Time	Low VOC	Below Grade?	Highlights	Min. Order	*Coverage	Unit Price
Bostik D321	Trowel	Wet/Flash	60-180 min	18-24 hrs	yes	yes	Zero VOC, superior strength	1	175 sf	\$149.99
Titebond 741	Trowel	Wet	30-60 min	12-24 hrs	yes	yes	Rapid cure (next day use!), mold/mildew resistant	10	125 sf	\$139.99
Titebond 821	Trowel	Wet/Flash	90-120 min	24-48 hrs	yes	yes	Mold and mildew resistant, superior green grab strength	10	125 sf	\$129.99
Titebond 811	Trowel	Wet/Flash	90-120 min	24-48 hrs	yes	yes	Long open time, easier to trowel than 821, cost efficient	10	125 sf	\$119.99
Titebond T&G	Bottle	Wet	5 min	24 hrs	yes	yes	Water resistant, low chalk temperature, 2 yr shelf life	1	**75 sf	\$7.75

Moisture Barriers

Product	Apply with	Sound Barrier	Work Time	Cure Time	Low VOC	Below Grade?	Highlights	Min. Order	*Coverage	Unit Price
Bostik D288	Trowel	yes	60-180 min	12-16 hrs	yes	yes	Sound barrier, 1 coat, Bostik BLOCKADE	1	175 sf	\$158.99
Titebond 531	Paint Roller	no	20-40 min	16-18 hrs	no	on or above	Roll on, 1 coat, tack free overnight, mold/mildew resistant	10	400 sf	\$168.99
Titebond 571	Trowel	yes	60-180 min	12 hrs	yes	above only	Sound barrier, 1 coat, tack free overnight, mold/mildew resistant	10	150 sf	\$138.99

*All coverage numbers are approximate. True coverage depends on multiple variables dependent on product type, thickness of application layer, etc.

**50 sf for Radiant, 100 sf for E Series

Wet Lay Method: In the "wet lay" method you do not flash the adhesive; you begin laying the wood flooring immediately after troweling the adhesive. Once the adhesive has been troweled, the wood flooring may be installed immediately into the wet adhesive. To reduce slippage, secure the first two starter rows with finishing nails or sprig nails. Remaining planks must be placed firmly into adhesive. Planks which are not flat should be weighted for several hours. In the wet lay method, you should not work on top of the wood.

Flash method: The "flashed" method is when the adhesive is allowed to flash for the recommended amount of time prior to installing the wood flooring. While using this method, you are advised to trowel out larger sections of the room so that you spend most of your time laying wood rather than flashing adhesive. Be careful not to exceed the open time and do not trowel more adhesive than you can comfortably cover with the flooring in two hours.

